

Thor M 2 Manual



- ① Install star caps or attachment here.
- ② Screw in/out to adjust the laser beam.
- ③ This laser uses 2 x 16340 Li-ion 3.7V batteries.
- ④ On/Off button.

Technical Specs

Name	Thor M 2
Size	21*3*3 cm
Laser Class	Class 4
Laser Type	Direct Diode
Wavelength	450nm blue
Output Power	1600mw, 3000mw
Laser Body	Aircraft-Grade Aluminum
Laser Finish	Black
Beam Divergence	3.6 mRad
Beam Diameter	4mm At Aperture, <20mm at 10 meters
Modes	Single On/Off Mode
Power Supply	2*16340 3.7V Lithium-Ion Rechargeable Battery
Weight	0.2kg

Important things:

- 1. Must use safety goggles.
- 2. Don't light up over 2 minutes each time, totally cool down before you use it again, if or, it may be damaged by overheated.
- 3. Keep away from children, don't direct to eyes. User is responsible for any improper using way.